



Advance Flooring Systems Ltd
+64 9 634 4455
(Call Free) AU 1800 459 682
(Call Free) NZ 0508 238262
info@advanceflooringsystems.com
www.advanceflooringsystems.com
PO Box 13184, Auckland 1643, New Zealand

AkoPlus Safety Matting – Installation Instructions

08/2018

Please note: For best results the subfloor must be dry, smooth and stable. It is recommended that AkoPlus Safety Matting is rolled out and acclimatised for a minimum of 24 hours.

To allow for the flow through of water, dirt and grit AkoPlus Safety Matting is best fixed down with stainless steel screws and washers rather than fixed with an adhesive.

Step 1.1 Check product supplied to you for correct colour and quantity, if multiple rolls please check rolls against one another for colour consistency – any questions please contact Advance Flooring Systems on 0508 238 262 or sales@advanceflooringsystems.com

Step 1.2 Measure your requirements and cut product to correct length and width using a sharp knife or scissors.

Step 1.3 Fix product to subfloor using stainless steel screws and washers at 300-400mm distance apart.

Step 1.4 Exposed edges of product can be protected with an edge bar or stair nosing if on the edge of stairs.

For further support please contact Advance Flooring Systems on 0508 238 262 or sales@advanceflooringsystems.com